

The Kice Dust Duct methodology was developed in the 1950's and has been refined over the years based on extensive experience. Great care and attention has been given to details such as branch entry angles, taper lengths and methods of construction. All of these small details add up to efficient and effective dust control systems.

Standard Dimensions – Collars and Flanges

Table 1, Collar Length	Dim "K"	Table 2, Circular Flange Dimensions			Table 3, Rectangular Flange Dim. and Hole Location Rules		
		Flange I.D.	Wide x Thick	Hole Spacing	Flange Length	Wide x Thick	
Diameter 12" or less	4"	12 1/2" or less	1 1/2" x 1/8"	8 holes @ 45°	12 1/2" or less	1" x 1/8"	
13" - 36" inclusive	5"	13" - 24 1/2"	1 1/2" x 3/16"	12 holes @ 30°	13" - 24 1/2"	1 1/2" x 3/16"	
37" - 48" inclusive	6"	25" - 36" incl.	1 1/2" x 3/16"	24 holes @ 15°	25" - 36" incl.	1 1/2" x 1/4"	

1. Holes on vert. & and horiz. 
2. Always center one hole in each corner.
3. Bolt hole in corner – first bolt hole from corner to be no less than 3", no greater than 6" – remaining bolt holes on 6" spacing.
4. All dimensions measure center to center.


Note 1: Collars for Dust Duct per Table 1 are to be connected by draw-type couplings - Kice type "CC" shown on page 2, this catalog.
Note 2: Bolt holes to be 3/8" dia. through flanges for 5/16" NC hex-head bolts. Bolts not furnished with Dust Duct components

Mild steel components for line sizes smaller than 18" are built out of 16 gauge. Line sizes 18" and larger are built out of 14 gauge. Mild steel is painted Kice white. Aluminum and stainless steel construction is available upon request.





































Weld seams are centered on top or bottom of components. Components with flanges have one bolt hole centered on the weld seam.

Part numbers start with a 2-Letter code for the specific item followed by numbers with dashes in between. Numbers go in sequence from A to B to C...and correspond to the diagrams in this catalog. Please refer to the catalog to properly define each part number. See Figure 1 for example.


5500 N. Mill Heights Drive
Wichita, KS 67219 USA
Phone: 316-744-7151
Fax: 316-744-7355
e-mail: sales@kice.com
www.kice.com
QuikShip Center
Toll Free: 1-877-289-5423
e-mail: quikship@kice.com








Dust Duct Manual
KICE DATA SHEET | DD-6

YP**ER****GS****CD Door Only**CUT HOLE IN DUCT
AS REQ.ON JOB**YA****EL****TN****CI****BS****SD****TS****CP****Notes:****BD****CC****TC****SS****CA**

ALL SIZES AVAILABLE

CR

ALL SIZES AVAILABLE

ST**CF****CG Gasket**

Sizing/Specification Data on Back

REV.		CHANGE		DATE BY	
SZ	DESCRIPTION	REV.	REV.	DATE	BY
D	KICE INDUSTRIES, INC. 5500 MILL HEIGHTS DR. WICHITA, KANSAS 67219 PH:(316) 744-7151 FAX:(316) 744-7355 DUST DUCT CATALOG	JBR	EA	EA	12-15-06
		1/8"	= 1' 0"	SCALE	REV. -
				DATE NO.:	XXX-XXX-XXXX